

# GSM Gateway User Manual



## Content of delivery

- Art Nr - 2236 GSM Gateway
- Antenna
- Art Nr 162236M - GSM Gateway Manual (this document)
- Power adapter 230VAC/12 VDC
- 2033 Modular cable
- Terminal connector

## Table of contents

1.	Installation .....	2
1.1	PIN code .....	2
1.1.1	PIN code deactivated .....	2
1.1.2	PIN code activated .....	2
1.2	Startup .....	3
1.3	Turn off the GSM Gateway .....	3
1.4	Change SIM card .....	3
2.	Front panel connectors and indications .....	4
3.	Back panel connectors and indications .....	5
4.	Battery .....	6
4.1	Low battery voltage indication .....	6
4.2	Battery fault alarm .....	6
5.	SMS functionality .....	7
5.1	Battery alarm .....	7
5.2	Dial tone 2 .....	10
6.	Upgrade Tool .....	11
6.1	Firmware upgrade .....	11
6.2	Setup .....	12
6.2.1	LED control on signal strength .....	13
6.2.2	Battery control .....	13
6.2.3	Gain control .....	13
6.2.4	POTS1 power saving .....	13
6.2.5	Tone generation .....	13
6.2.6	Battery failure signal – dial tone 2 .....	13
	Notes: .....	15
7.	Technical Data .....	16
8.	Contact Information .....	16

## 1. Installation

Find a suitable place where to mount the GSM gateway following these guide lines:

- Make sure the GSM coverage is good before the GSM gateway is mounted. Place the Gateway near a window if possible.
- Make sure the LEDs on both sides are visible.
- Make sure there is a power source, 230 VAC or 12-24 VDC reachable.
- Connect the antenna. Place the antenna as far away from the Gateway as possible. If the Gateway is near a window; clean the window, remove the cover from the adhesive tape and stick the antenna to the window. You can also use a cable tie to fix the antenna.
- Connect the FältCom ECII® Flex to the Phone input. Use the 2033 Modular cable and the terminal connector if required.

### 1.1 PIN code

*Note: The GSM gateway must always be turned off before inserting or removing the SIM card. Please see section “Turn off the GSM Gateway” before removing a SIM card.*

Choose whether the PIN code should be activated or deactivated.

#### 1.1.1 PIN code deactivated

Use a mobile phone or other equipment to deactivate the PIN code on the SIM card.

#### 1.1.2 PIN code activated

The PIN code must be set to “1234”. Use a mobile phone or other equipment to set the PIN code to “1234”.

At startup the GSM Gateway will automatically change the PIN code to a random 4-digit code to prevent misuse of the GSM unit. If the SIM card is to be used later; use the PUK code to unlock the SIM.

## 1.2 Startup

Start the GSM Gateway:

- Gently insert the SIM-card into the GSM unit as shown in the pictures below. Make sure the cut corner of the SIM is on the left side and the connector pads facing down.



- Connect the power cable. The startup might take up to 30 seconds before the GSM Gateway has established a connection with the GSM network. For information on how to understand the LED indications, please see section 2 and section 0 nedan.

## 1.3 Turn off the GSM Gateway


1. Remove the DC power connector from the GSM Gateway.
2. Push the RESET button with a short push to turn the unit off.

## 1.4 Change SIM card

If the SIM-card needs to be changed; the new SIM-card must have "1234" as PIN-codes or have the PIN-code deactivated.

1. Turn off the GSM Gateway; remove the DC power connector from the GSM Gateway.
2. Push the RESET button with a short push to turn the unit off.
3. Remove the old SIM and insert the new SIM as shown in the pictures above.
4. Connect the power cable.

## 2. Front panel connectors and indications




**USB** USB 2.0 Mini connector to be used for connection with a PC. The USB can be used for updating the software of the GSM Gateway and also for adjusting parameters, such as battery tripping limits. For more information please see section 6 "Upgrade Tool".


### LED Indicators

LED	Status	Indicates
PWR/STAT	1000 ms ON / 1000 ms OFF	Normal status
	100 ms ON / 1500 ms OFF	Backup power in use
PHONE (Red LED)	ON	Off-hook of the connected telephone device
	Flashing	Ringing signal
BATT (Red LED)	Flashing	Battery problem. The battery is not connected or the battery has not passed a battery test. See also section 4 nedan.

**PHONE** Connection to standard telephone device

	<b>No</b>	<b>PHONE (RJ11)</b>
	1	
	2	La
	3	Lb
	4	

### 3. Back panel connectors and indications



- ANT** SMA connector for the antenna
- SIM** Input of the SIM card
- GSM** Status for the GSM connection when the GSM Gateway is up and running (Green LED):

<b>GSM</b>	<b>Indicates</b>
OFF	Faulty GSM unit
800 ms ON / 800 ms OFF	No service, No connection with GSM or SIM-card missing.
100 ms ON / 1500 s OFF	Connection with the GSM network OK, Backup power in use
ON	Normal status. Connection with the GSM network OK , AC-powered

**S1 and S2** Indications for GSM signal strength (Green LED):

<b>S1</b>	<b>S2</b>	<b>Signal strength</b>
OFF	OFF	Bad
ON	OFF	Good ( default 15 = -83 dBm)
ON	ON	Very good ( default 25 = -63 dBm)
Flash	OFF	Good, Backup power in use.
Flash	Flash	Very good, Backup power in use.

LED levels are programmable in 2 dB steps from -113 dBm to -51 dBm via USB (1258 Manager)

<b>12V DC</b>	<b>12V DC</b>	<b>No</b>	<b>PWR</b>
	—  +	+	+ 9-28 V DC
		-	GND

#### RESET

<b>Type of RESET activation</b>	<b>Power supply</b>	<b>Result</b>
Short push	External	Reboot of GSM Gateway
Short push	Battery	GSM Gateway is switched off
Hold button for >20 s	External	All settings are reset to factory settings. This is indicated by the LED's <b>PHONE</b> and <b>BATT</b>

*Note: Factory reset also changes the PIN-code back to the default "1234" if PIN –code is in use, this may cause the SIM-card to be locked if a SIM-card is mounted inside the GSM Gateway.*

## 4. Battery

The battery is supervised in two different ways. The first “low battery voltage indication” is activated when the battery voltage is too low for any reason. The second is a “battery fault alarm” activated when the battery capacity is too low and it is time to replace the battery.

In case there is a battery alarm/low battery voltage indication, the GSM Gateway will change the dial tone; see section Technical Data for information on dial tone 2 specifications. The emergency alarm will detect the new dial tone and send a battery alarm to the receiver. See section 5 SMS functionality for information on how to turn the dial tone 2 off.

### 4.1 Low battery voltage indication

A “low battery voltage indication” is shown by a red LED, see section 2 above, and by a change of the normal dial tone, see section 5.2 nedan and can be activated by any of the following reasons: (This check is done every 30 s)

- The battery is not mounted
- The battery voltage drops below 4.4 VDC when the unit is connected to mains power.
- The battery voltage drops below 4.2 VDC when the unit is powered by the battery

If the unit is powered by the battery and the battery voltage drops below 4.0 VDC the GSM Gateway will shut off to prevent permanent damage of the battery. These voltage levels are not programmable.

### 4.2 Battery fault alarm

A “battery fault alarm” is indicated the same way as “low battery voltage indication” (4.1) but can also be sent by SMS. Please view SMS functionality for information on settings or how to use the USB connector and 1258 Manager software.

The first battery test is made after 48 hours and the following every 24 hour. During a battery test a load is connected to the battery and the battery voltage measured. A battery test lasts for 5<sup>(1)</sup> minutes and if the voltage drops below 4.4<sup>(2)</sup> VDC during this time a “battery fault alarm” is activated.

A battery test will not be performed when the GSM Gateway is powered by the battery. An active “battery fault alarm” is automatically reset after a passed battery test.

Normally the battery will last 2-4 years but this is very much depending on the surrounding temperature and how much the battery is used. When the battery is failing only replace the battery with an equivalent type. Other types of battery might damage the GSM Gateway.

A polyswitch fuse is integrated in the battery package to prevent it from damage in case of high temperatures. The fuse is automatically reset when the temperature is normal again.

(1) 5 minutes is the default setting. The time is programmable via USB (1258 Manager).

(2) 4.4 V is the default setting. The levels for the “battery fault alarm” is programmable via USB (1258 Manager) or via SMS by the distributor.

## 5. SMS functionality

Note: The symbol ↵ means new line.

### 5.1 Battery alarm

It is possible to generate an SMS when a battery fault alarm occurs and the functionality is activated by sending an SMS to the GSM Gateway. The SMS must include the telephone number and an alarm text. The SMS is not case sensitive. See picture below for an example. In the example below the battery alarm level is not changed.



*SMS to GSM Gateway*



*SMS from GSM Gateway*

The GSM will acknowledge a correct programming by returning a SMS as above.

In the example below the battery alarm level is changed to 4.0 V (4000 mV).



*SMS to GSM Gateway*



*SMS from GSM Gateway*


The GSM will acknowledge a correct programming by returning a SMS as above.

In this example a battery alarm will generate the following SMS from the GSM Gateway:



*SMS from GSM Gateway*

It is possible to generate an SMS (Bares) when the battery is replaced to a new one after a Battery fault alarm. This function is activated by sending an SMS to the GSM Gateway. The SMS must include an appropriate text. The SMS is not case sensitive. See picture below for an example. Bares SMS is always sent to the same number as Balarm.



*SMS to GSM Gateway*



*SMS from GSM Gateway*

The GSM Gateway will acknowledge a correct programming by returning a SMS as above.

In this example when the battery is changed it will generate the following SMS from the GSM Gateway:



*SMS from GSM Gateway*

Both functions described above are switched off by sending the following SMS to the GSM Gateway:



*SMS to GSM Gateway*



*SMS from GSM Gateway*

The SMS is acknowledged with a SMS from the GSM Gateway.

The Battery replaced SMS (Bares) function described above can be switched off separately by sending the following SMS to the GSM Gateway:



*SMS to GSM Gateway*



*SMS from GSM Gateway*

The SMS is acknowledged with an SMS from the GSM Gateway.

## 5.2 Dial tone 2

The dial tone 2 indicating a battery alarm/low battery voltage indication, to the lift phone is default activated but can be turned off. In case the function is deactivated the GSM Gateway will always use dial tone 1 when the line is taken off-hook.

To deactivate the dial tone 2 (battery alarm/low battery voltage indication, dial tone) off; send the left side SMS to the GSM Gateway. The Gateway will return the answer on the right side.



*SMS to GSM Gateway*



*SMS from GSM Gateway*

To reactivate the dial tone 2 (battery alarm/low battery voltage indication, dial tone); send the left side SMS to the GSM Gateway. The Gateway will return the answer on the right side.



*SMS to GSM Gateway*




*SMS from GSM Gateway*

## 6. Upgrade Tool

The USB interface is used to configure user specific parameters and to upgrade the GSM Gateway firmware. The upgrade requires the Windows program “1258 Manager” and is available from FältCom or your local distributor. Use a standard USB – mini USB cable to connect the GSM Gateway to the PC.

- Install the “1258 Manager” tool on your PC.
- Connect the GSM Gateway to the PC using a standard USB – mini USB cable.
- Start the “1258 Manager” by clicking the icon 




When the GSM Gateway is connected to the Manager tool the status bar at the bottom will show “1258 attached”

Push “Get” to see the GSM Gateway Firmware and Hardware versions. In this example FW 3.11 and HW 3.

### 6.1 Firmware upgrade

To upgrade the GSM Gateway Firmware select the “FW update” tab.




- Click on “Select file”


- Brows to find and select the new FW file supplied by FältCom or your local distributor.  
Note: The FW file always has the file extension bin (e.g. gatewayFW.**bin**).
- Click on “Update”. During the update you can follow the progress in the status bar.  
Note: Be careful not to disconnect the power during FW upgrade.

## 6.2 Setup

For configuration of user specific settings use the “Setup” tab and click on “Get setup”



A new window will appear showing all configurable settings.



### 6.2.1 LED control on signal strength

There are two LED's showing the strength of the GSM signal; S1 and S2. You can set the limits when to light these LED's.

### 6.2.2 Battery control

For information on the battery control please see the section 4 Battery.

- Fill out the "GSM Battery alarm nr"; where to receive battery alarm SMS.
- Fill out the "GSM Battery alarm text"; SMS text from the Gateway in case of battery alarm.  
E.g. Battery alarm from lift 4435.
- Fill out the "GSM Battery reset text"; SMS text from the Gateway when the battery is replaced.  
E.g. Battery reset from lift 4435.

### 6.2.3 Gain control

Gain control is used to amplify or attenuate the signals between the GSM network and the PHONE line from the Gateway to the emergency alarm. The signal gain can be set on both GSM to POTS and POTS to GSM. Please note that POTS is the analogue line PHONE generated by the GSM Gateway.

Changing the GSM to POTS (PHONE) to positive values will amplify the signal received on the GSM transmitted to the PHONE. Changing to negative values will attenuate the signals to the PHONE.

Changing the POTS (PHONE) to GSM to positive values will amplify the signal received from the PHONE transmitted to the GSM network. Changing to negative values will attenuate the signals to the GSM network.

The signal gain and quality of the GSM system differs between countries and you may therefore be required to change the signal gain to adjust for these differences. If the emergency alarm has trouble receiving and deciphers DTMF sent by the receiver; try adjusting the GSM to POTS (PHONE). Start by trying negative values, if the result does not improve; try positive values.

If the receiver has trouble receiving and deciphers DTMF sent by the emergency alarm; try adjusting the POTS (PHONE) to GSM.

### 6.2.4 POTS1 power saving

Note: Do not use this feature for any emergency alarm systems. This feature can be used when connecting the Gateway to a regular phone.

The power save will disconnect the PHONE line power during a pre-defined time. Operating modes are "Off", "Always on" and "Battery only".

Battery only mode will enable the function only during battery operation to increase the battery operation time.

After selecting operating mode; set:

**Total cycle time** – Cycle time for power save operation. E.g. select cycle time to 1 second; set the Total cycle time (ms\*10/steps) to 100 (=1000ms).

**Power up time** – Time of operation during the cycle time. E.g. if the cycle time is set to 1 second and you want the Gateway to power the PHONE during 50% of the time; set the Power up time (ms\*10/steps) to 50 (=500ms).

### 6.2.5 Tone generation

The GSM Gateway can generate line tones on the PHONE line according to different country specific preferences. There are a few pre-programmed countries:

France, Germany, Great Britain, Italy and Spain.

Germany and Italy are the same setting and this is also the EU recommendation for PSTN line tones.

When using the GSM Gateway with an emergency phone; please use German, Italian or Spanish settings even if installed in other countries.

### 6.2.6 Battery failure signal – dial tone 2

There are two ways the Gateway can signal a battery failure, one is by SMS and that is presented in section 5. The second way is by signalling on the PHONE analogue line.



Setting the GSM Gateway to generate the dial tone 2, indicating a battery failure. When a battery failure occurs the Gateway will send a congested tone instead of the normal continuous dial tone. The dial tone 2 is 1000ms ON / 250ms OFF / 250ms ON / 250ms OFF. To configure this setting set:

“Dial/Congestion tone, battery fault” to “425 Hz, 1000/250/250/250 ms”.

This setting is default active.

The emergency alarm must be programmed accordingly in order to detect the battery alarm signal from the Gateway; please see the manual for the emergency alarm if that setting is available.





## 7. Technical Data

<b>Parameter:</b>	<b>Data:</b>
Size (L x B x H):	165 x 140 x 25 mm
Weight:	558 g, with battery and antenna included
Protection class:	IP 20
External power:	10-28 VDC
Power consumption	At rest: 12V < 150 mA, 24V < 75 mA Ongoing call: 12V < 450 mA, 24V < 225 mA
Battery type:	NiMH 4,8V 1250 mAh High Temp
Battery power consumption:	At rest: about 225mA. Ongoing call: < 550mA I.E. 2h including 3 x 3 minute calls.
GSM module:	Siemens M55i (Quad-Band 850/900/1800/1900 MHz)
Antenna:	50 Ohm SMA-connector, 870–960 MHz/1710–1990 MHz
Line voltage on hook:	48 V DC
Polarity reversal:	Yes
Operating temperature:	+5 °C to +40 °C
Air humidity:	30 % to 90 % RH
Approvals:	TBD

### Tone indications

Dial tone 1:	425 Hz -10 dBm. Continuous
Dial tone 2 (battery failure):	425 Hz -10dBm. 1000ms ON / 250ms OFF / 250ms ON / 250ms OFF, continuous
Congestion tone:	425 Hz -10dBm. 200ms ON / 200ms off / 200ms ON / 200ms OFF / 200ms ON / 600ms OFF, continuous
Ring tone:	25 Hz 40 VRms into 3REN. 1500 ms ON / 3000 ms OFF
Ring back tone:	1500 ms ON / 3000 ms OFF
Busy tone:	200 ms ON / 200 ms OFF

### Connections

Telephone:	RJ-11
Antenna connector:	SMA
DC power supply input	DC Plug 2.1mm/5.5mm
USB:	USB 2.0 Mini

## 8. Contact Information

### Support:

Tel:+ 46 (0)90 18 39 27

E-mail: support.liftphones@faltcom.se

Fält Communications AB  
Vasagatan 23  
SE-903 29 UMEÅ, Sweden

**Phone:** + 46 (0)90 18 39 00

**Fax:** + 46 (0)90 18 39 29

**Homepage:** www.faltcom.se

### Service address:

Fält Communications AB  
c/o BL Elektronik AB  
Furuhedsvägen 1  
SE-952 31 KALIX, Sweden